TOP AND CONSOLE PARTS

27"GAS DRYER

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8299800	Label, Wiring Diagram
	LIT8529302	Guide, Use & Care
	LIT3979173	Instructions, Installation
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	LIT677818	Manual, Do−It−Yourself Repair (Dryer)
2	8317305	Panel, Rear Console
3	3406725	Timer
4	3400859	Screw, Grounding (8−18 x 7/32)
5	3398094	Switch, Push−To−Start
6	3391885	Connector, Edge
7	3395683	Connector (Motor)
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	8271316	Bracket, Control
10	3390646	Screw, 8−18 x 5/16
11	3401850	Harness, Gas
12	388326	Screw, Console
13	3405155	Switch, Temperature
14	3391018	Tie, Cable (Push−Mount)
15		Knob, Control (3)
	8271339	White
	8271348	Biscuit
16	3397269	Connector, Timer
17	717252	Receptacle, 2−Way
18	3403499	Connector, 2−Position (Gas Valve)
19	8299941	Harness, Wiring
20		Timer Knob Assembly
	8312687	White
	8271404	Biscuit
22	8318255	Strap, Console
23	357213	Nut, Push−In (2)
24		Top
	8271399	White
	8271401	Biscuit
25	3405152	Switch, End Of Cycle
26		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
27	3936144	Connector
28	3403498	Connector, 3−Position (Gas Valve)
29	3390537	Control, Electronic
30	694419	Buzzer, Mini
31		Panel, Control
	3978119	White
	3978120	Biscuit
32	3405154	Switch, Finish Guard
33		Knob, Push−To−Start
	8271341	White
	8271349	Biscuit
34	697779	Plug, 3−Way
35	3390647	Screw, 8−18 x 1/2
37	3401144	Connector (PTS Relay)
40	3347243	Connector, 6−Circuit
41	3394427	Clip, Harness
44	94614	Terminal

CABINET PARTS

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8317340	Cover, Terminal Block
2	3390814	Screw, 8−18 x 3/8
3	3390647	Screw, 8−18 x 1/2
4	3394331	Plate, Cover
5	3394881	Switch, Broken Belt
6	344020	Cord, Power
7		Cabinet
	8310656	White
	8310659	Biscuit
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12		Plug, Multivent
	697750	White
	3388311	Biscuit
13	3388672	Pulley Assembly
14	3390663	Screw, 10−16 x 1/2
15	697776	Screw, Ground
16	3398948	Wire, Jumper (Broken Belt Switch)
17	3395532	Exhaust Pipe & Bracket
18	233520	Washer, Thrust
19	297092	Clip (2)
20	690997	Tri Ring
21	3387560	Hinge, Door (R.H.)
	3387559	Hinge, Door (L.H.)
22	3387565	Spring, Door (2)
23	3391408	Lever, Snap Switch
24	3394081	Wire, Belt Switch
25	49026	4" − 90° Elbow
26	3393657	Restrainer, Belt
27	3395654	Motor, Assembly 60 HZ.
28	3395534	Exhaust Pipe (Short)
29	3389729	Pulley 60 HZ.
30	3387610	Belt, Drive
31	693152	Bumper
32	3387118	Bracket, Motor
33	3395535	Exhaust Pipe (Long)
34	3388600	Clip, Lint Duct
35	98129	Screw, 6−20 x 1 3/8
36	693995	Screw, 8−18 x 3/8
39	3388674	Idler Bracket
40	3357011	Screw, 10−16 x 1/2
41	3392266	Switch, Door
44	3387242	Seal, Front Panel
46	3388229	Retainer
47	697655	Door, Rear
48	694091	Screw, 8−18 x 3/8
49		Door, Front
	697221	White
	3977763	Biscuit
50	691581	Lever, Door Switch
51		Upper Front Panel
	697227	White
	3977761	Biscuit
52	696144	Strike, Door
57	3390736	Seal, Door
58	690081	Catch, Door Assembly
60		Handle, Door
	690270	White
	3977242	Biscuit
61		Toe, Panel
	697215	White
	3977764	Biscuit

Optional Parts Not Included

Dryer Exhaust Kit
(For Side & Bottom Venting)

62	279818	White
	279925	Biscuit

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit(Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	90767	Screw, 8−18 x 3/8
4	3394986	Spring, Lint Screen Door
5	3394346	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3359452	Nut,3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	3390646	Screw, 8−18 x 5/16
11	3403634	Socket Assembly
12	3388229	Clip
13	3392258	Ground−Sensor
14	3394984	Door, Lint Screen
15	8318486	Exhaust Pipe
16	3387709	Nut, 3/8−16 (L.H.)
17	8520836	Bulkhead, Rear
18	3387459	Washer, Support
19	3399509	Shaft, L.H. Thread
20	690997	Ring, Tri
21	3396801	Roller, Support
23	3394985	Outlet Housing Assembly
25	8318215	Complete Drum Assembly
26	97787	Screw, 11−16 x 3/4
27	697694	Seal, Drum
34	3387223	Electrode, Sensor
35	3402841	Lens, Drum Light
36	3406124	Bulb, Light
37	697772	Wheel, Blower
38	3977373	Bracket, Drum Light
42	8318268	Thermostat, Internal Bias
43	3403140	Thermostat, High−Limit 205°F (96°C)
44	697363	Housing, Blower
45	3390531	Lint Duct Assembly
46	8066047	Funnel, Burner
48	338906	Sensor, Radiant
51	3387230	Screw, 10−16 x 1
52	697771	Cover, Blower (Includes Illus. No. 62)
53	697693	Baffle, Drum
54	697557	Bulkhead, Front
58	8299979	Grill, Outlet
59	3390719	Thermal Fuse
60	697770	Seal, Cover Plate
62	697769	Seal, Lint Duct
64	3390721	Lint, Screen
65	487909	Screw, 8−15 x 1/2

8318276 BURNER ASSEMBLY

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



8318276 BURNER ASSEMBLY

For Models: GGQ8811KQ0, GGQ8811KT0
(Designer White) (Biscuit)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318276	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 7/8)
6	343641	Screw, 10−16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318281	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8−18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support
Following Parts Not Illustrated		
	694572	Conversion Kit (Type (1) to Type (4) LPG).

BA−149